



Assembly and operating instructions

REMKO MKT 251, MKT 251 S-Line

Local Air Conditioner





Read these operating instructions carefully before commissioning / using this device!

These instructions are an integral part of the system and must always be kept near or on the device.

Subject to modifications; No liability accepted for errors or misprints!

Installation and operating instructions (translation of the original)

Table of contents

1	Safety and usage instructions	4
1.1	General safety notes.....	4
1.2	Identification of notes.....	4
1.3	Personnel qualifications.....	4
1.4	Dangers of failure to observe the safety notes.....	4
1.5	Safety-conscious working.....	4
1.6	Safety notes for the operator.....	5
1.7	Safety notes for installation, maintenance and inspection.....	5
1.8	Unauthorised modification and changes.....	5
1.9	Intended use.....	5
1.10	Warranty.....	5
1.11	Transport and packaging.....	6
1.12	Environmental protection and recycling.....	6
2	Technical data	7
2.1	Unit data.....	7
3	Design and function	8
4	Operation	9
5	Assembly and installation	11
6	Electrical wiring	15
7	Commissioning	16
8	Troubleshooting and customer service	17
9	Care and maintenance	19
10	Shutdown	20
11	Exploded view and spare parts lists	21
11.1	Exploded view of the unit	21
11.2	Spare parts list	22
12	Index	24

REMKO MKT

1 Safety and usage instructions

1.1 General safety notes

Carefully read the operating manual before commissioning the units for the first time. It contains useful tips and notes such as hazard warnings to prevent personal injury and material damage. Failure to follow the directions in this manual not only presents a danger to people, the environment and the system itself, but will void any claims for liability.

Keep this operating manual and the refrigerant data sheet near to the units.

1.2 Identification of notes

This section provides an overview of all important safety aspects for proper protection of people and safe and fault-free operation. The instructions and safety notes contained within this manual must be observed in order to prevent accidents, personal injury and material damage.

Notes attached directly to the units must be observed in their entirety and be kept in a fully legible condition.

Safety notes in this manual are indicated by symbols. Safety notes are introduced with signal words which help to highlight the magnitude of the danger in question.

DANGER!

Contact with live parts poses an immediate danger of death due to electric shock. Damage to the insulation or individual components may pose a danger of death.

DANGER!

This combination of symbol and signal word warns of a situation in which there is immediate danger, which if not avoided may be fatal or cause serious injury.

WARNING!

This combination of symbol and signal word warns of a potentially hazardous situation, which if not avoided may be fatal or cause serious injury.

CAUTION!

This combination of symbol and signal word warns of a potentially hazardous situation, which if not avoided may cause injury or material and environmental damage.

NOTICE!

This combination of symbol and signal word warns of a potentially hazardous situation, which if not avoided may cause material and environmental damage.



This symbol highlights useful tips and recommendations as well as information for efficient and fault-free operation.

1.3 Personnel qualifications

Personnel responsible for commissioning, operation, maintenance, inspection and installation must be able to demonstrate that they hold a qualification which proves their ability to undertake the work.

1.4 Dangers of failure to observe the safety notes

Failure to observe the safety notes may pose a risk to people, the environment and the units. Failure to observe the safety notes may void any claims for damages.

In particular, failure to observe the safety notes may pose the following risks:

- The failure of important unit functions.
- The failure of prescribed methods of maintenance and repair.
- Danger to people on account of electrical and mechanical effects.

1.5 Safety-conscious working

The safety notes contained in this manual, the existing national regulations concerning accident prevention as well as any internal company working, operating and safety regulations must be observed.

1.6 Safety notes for the operator

The operational safety of the units and components is only assured providing they are used as intended and in a fully assembled state.

- The units and components may only be set up, installed and maintained by qualified personnel.
- Protective covers (grille) over moving parts must not be removed from units that are in operation.
- Do not operate units or components with obvious defects or signs of damage.
- Contact with certain unit parts or components may lead to burns or injury.
- The units and components must not be exposed to any mechanical load, extreme levels of humidity or extreme temperature.
- Spaces in which refrigerant can leak sufficient to load and vent. Otherwise there is danger of suffocation.
- All housing parts and device openings, e.g. air inlets and outlets, must be free from foreign objects, fluids or gases.
- The units may not be used in environments containing a great deal of dust or chlorine, or in places with atmospheres containing ammonia.
- The units must be inspected by a service technician at least once annually. Visual inspections and cleaning may be performed by the operator when the units are disconnected from the mains.
- The local room air conditioner is designed for flexible use in living and work spaces. Year-round operation is not recommended.
- Do not leave the appliance running for an extended period unsupervised.

1.7 Safety notes for installation, maintenance and inspection

- Appropriate hazard prevention measures must be taken to prevent risks to people when performing installation, repair, maintenance or cleaning work on the units.
- The setup, connection and operation of the units and its components must be undertaken in accordance with the usage and operating conditions stipulated in this manual and comply with all applicable regional regulations.
- Local regulations and laws such as Water Ecology Act must be observed.
- The power supply should be adapted to the requirements of the units.
- Units may only be mounted at the points provided for this purpose at the factory. The units may only be secured or mounted on stable structures, walls or floors.

- Mobile units must be set up securely on suitable surfaces and in an upright position. Stationary units must be permanently installed for operation.
- The units and components should not be operated in areas where there is a heightened risk of damage. Observe the minimum clearances.
- The units and components must be kept at an adequate distance from flammable, explosive, combustible, abrasive and dirty areas or atmospheres.
- Safety devices must not be altered or bypassed.

1.8 Unauthorised modification and changes

Modifications or changes to units and components are not permitted and may cause malfunctions. Safety devices may not be modified or bypassed. Original replacement parts and accessories authorised by the manufacturer ensure safety. The use of other parts may invalidate liability for resulting consequences.

1.9 Intended use

Depending on the model, the equipment and the additional fittings with which it is equipped is only intended to be used as an air-conditioner for the purpose of cooling or heating the air in an enclosed room..

Different or additional use shall not be classed as intended use. The manufacturer/supplier assumes no liability for damages arising from an unintended use of the equipment. The user bears the sole risk in such cases.

Using the equipment as intended also includes working in accordance with the operating manual and installation instructions and complying with the maintenance requirements.

Under no circumstances should the threshold values specified in the technical data be exceeded.

1.10 Warranty

For warranty claims to be considered, it is essential that the ordering party or its representative complete and return the "certificate of warranty" to REMKO GmbH & Co. KG at the time when the units are purchased and commissioned.

The warranty conditions are detailed in the "General business and delivery conditions". Furthermore, only the parties to a contract can conclude special agreements beyond these conditions. In this case, contact your contractual partner in the first instance.

REMKO MKT

1.11 Transport and packaging

The devices are supplied in a sturdy shipping container. Please check the equipment immediately upon delivery and note any damage or missing parts on the delivery and inform the shipper and your contractual partner. For later complaints can not be guaranteed.

 **WARNING!**

Plastic films and bags etc. are dangerous toys for children!

Why:

- Leave packaging material are not around.
- Packaging material may not be accessible to children!

1.12 Environmental protection and recycling

Disposal of packaging

All products are packed for transport in environmentally friendly materials. Make a valuable contribution to reducing waste and sustaining raw materials. Only dispose of packaging at approved collection points.



Disposal of equipment and components

Only recyclable materials are used in the manufacture of the devices and components. Help protect the environment by ensuring that the devices or components (for example batteries) are not disposed in household waste, but only in accordance with local regulations and in an environmentally safe manner, e.g. using certified firms and recycling specialists or at collection points.



2 Technical data

2.1 Unit data

Series		MKT 251	MKT 251 <i>S-LINE</i>
Operating mode		Local compact air conditioning unit for cooling	
Nominal cooling output ¹⁾	kW	2.60	
Energy efficiency ratio - cooling		A	
Energy efficiency rating EER ¹⁾		2.63	
Energy consumption, hourly	kWh/60 min	0.99	
Approx. application area (room volume)	m ³	80	
Adjustment range indoor unit	°C	+16 to +32	
Operating range - indoor unit	°C/%r.F.	+16 to +35 / +35 to +85	
Refrigerant		R 410A ³⁾	
Refrigerant, basic capacity	kg	0.5	
Max. operating pressure / cooling cycle	kPa	1800 / 3600	
Air flow volume per stage	m ³ /h	240 / 270 / 320	
Sound pressure level per stage ²⁾	dB(A)	49 / 52 / 53	
Sound power level max.	dB(A)	62	
Power supply	V/Ph/Hz	230 / 1~/ 50	
Enclosure class	IP	20	
Electr. rated power consumption ¹⁾	kW	0.99	
Electr. rated current consumption ¹⁾	A	4.78	
Elec. starting current max., LRA	A	17	
Exhaust air hose, length / diameter	mm	1500 / 125	
Dimensions - height	mm	770	
Dimensions - width	mm	435	
Dimensions - depth	mm	430	
Weight	kg	33.0	
Standard colour		white	silver
Serial number		1254...	1255...
EDP no.		1612255	1612256

¹⁾ Room air temperature TK 35 °C, FK 24 °C

²⁾ Distance 1m free field

³⁾ Contains greenhouse gas according to Kyoto protocol

REMKO MKT

3 Design and function

Unit description

The local air conditioning unit is particularly well suited to flexible use.

The local room air conditioner comprises a floor-standing unit for the indoor area and an exhaust air hose to conduct the heat away. The indoor unit extracts the heat from the room to be cooled by means of an evaporator (heat exchanger) and transfers it to the internal cooling cycle. This releases the heat back to the outside via another heat exchanger (condenser) by means of the flexible exhaust air hose.

The condensate arising during cooling mode is continually drained off via the condenser by means of a condensate pump located in the unit - the condenser evaporates the condensate and discharges it to the outside via the exhaust air hose.

The unit filters and dehumidifies the air thereby creating a comfortable room climate. It works fully automatically and offers numerous additional options thanks to its microprocessor controller. The unit can be conveniently operated by means of the infrared remote controller included.



Fig. 1: Front view

- A: Air inlet, recirculation
- B: Air outlet, recirculation
- 1: Recessed grip
- 2: Infra-red receiver
- 3: Ventilation louvres
- 4: Control panel
- 5: Conveyor rollers




Fig. 2: Rear view

- A: Air inlet, recirculation
- B: Air outlet, exhaust air
- 1: Air filter, recirculation
- 2: Condensate drainage with stopper
- 3: Exhaust air hose

4 Operation

The system can be operated by means of the control panel on the unit or via the standard infrared remote controller. The functional operation of the keys among themselves is identical, however, the designation can vary. The batteries must be correctly inserted before the infrared remote control is used.




Fig. 3: Control panel

Legend

① On / off "Power" key

② Operating mode "MODE" key

③ "Fan Speed" key

④ "Timer" key

⑤+⑥ keys

Temperature/time adjustment

"Timer/Temp Adjust":

⑤ Higher, ⑥ lower

⑦ Display

⑧ Red malfunction LED:

Reservoir full

An acoustic and optical signal indicates that the liquid level switch in the internal reservoir has switched off the operation of the unit. The acoustic signal ceases after a short time, the LED remains active.

⑨ LED operating mode indicator

Green: "Cool" orange: "Dehumidify" yellow: Ventilate "Fan"

⑩ Orange LED indicator

Fan stages with "High"/"Med"/"Low" fan speeds

⑪ Green LED indicator

"Timer"

⑫ Green LED indicator

"Room Temp"

(If this LED illuminates the current room temperature is shown in the display (⑦))

⑬ Green LED indicator

Target temperature "Set Temp"

⑭ Infra-red receiver

⑮ "°C/°F" changeover key

(Only on the remote control)

⑯ Infrared transmitter

(Only on the remote control)

REMKO MKT




Fig. 4: Infrared remote control

Selection of the operating mode "Mode"

- **Cooling "Cool"**
The unit provides room cooling. It filters and dehumidifies the air thereby creating a comfortable room climate.
- **Dehumidifying "Dehumidify"**
In dehumidifying mode moisture is removed from the air in the room.
- **Ventilate "Fan"**
The unit recirculates the room's air, filters it and provides an even air flow.

Cooling mode "Cool"

1. ➤ Attach the exhaust air hose to a wall pass-through or window
2. ➤ Switch the unit on with the "Power" key ①.
3. ➤ Press the "Mode" key ② until the "Cool" LED ⑨ illuminates.
4. ➤ Select the setting for the fan via the "Fan speed" key ③:
"High" highest fan speed
"Med" medium fan speed
"Low" lowest fan speed.
5. ➤ If the "Room Temp" LED ⑫ illuminates the current room temperature is shown in the display ⑦.
6. ➤ As soon as the ④/⑤/⑥ key is pressed, the display changes over from room temperature to target temperature (LED ⑬ illuminates) and shows the desired temperature for 15 seconds.
7. ➤ Adjust the desired room temperature via the "Timer/Temp Adjust" ⑤/⑥ key. The up arrow ⑤ increases the setpoint shown in the display ⑦, the down arrow ⑥ decreases the setpoint displayed.

Dehumidifying mode "Dehumidify"

1. ➤ Attach the exhaust air hose to a wall pass-through or window
2. ➤ Switch the unit on with the "Power" key ①.
3. ➤ Press the "Mode" ② key until the "Dehumidify" ⑨ LED illuminates, the fan will be automatically switched on at the "Med" fan speed.

Ventilate mode "Fan"

1. ➤ Switch the unit on with the "Power" key ①.
2. ➤ Press the "Mode" key ② until the "Fan" LED ⑨ illuminates.
3. ➤ Select the setting for the fan via the "Fan speed" key ③:
"High" highest fan speed
"Med" medium fan speed
"Low" lowest fan speed
4. ➤ The room temperature is not affected and remains constant. For this reason the "Timer/Temp. Adjust" keys ⑤/⑥ cannot be used.

"Timer"

You can switch the unit on and off automatically with the timer. The switch on delay or switch off delay can be programmed for this.

Automatic switch on

1. ➤ Switch the unit on with the "Power" key ①.
2. ➤ Select the operating mode and implement all settings for the desired operating mode.
3. ➤ Switch the unit off with the "Power" key ①.
4. ➤ Press the "Timer" ④ key.
5. ➤ Adjust the time via the "Timer/Temp. Adjust" ⑤/⑥ key. You can only enter full hours.
6. ➤ LED ⑪ flashes.

Automatic switch off

1. ➤ The unit operates in the previously selected operating mode.
2. ➤ Press the "Timer" ④ key.
3. ➤ Adjust the remaining runtime via the "Timer/Temp. Adjust" ⑤/⑥ key. Only full hours can be entered.
4. ➤ LED ⑪ illuminates.
5. ➤ Unit switches off automatically after the preset time.

! NOTICE!

You will achieve a pleasant room temperature if you set the desired target temperature max. 4 to 7 °C below the outside temperature.



Help save on energy consumption in stand-by mode! If the device, system or component is not in use, we recommend disconnecting the power supply. Components with a safety function is excluded from our recommendation!

5 Assembly and installation

Assembly and unit installation instructions

The unit is positioned at the desired location with the discharge side pointing into the room. When positioning, observe the following instructions:

- After unpacking the unit let it sit on its transport rollers for at least 5 minutes before you switch it on.
- Set the unit down in a stable position on a level and firm floor. If the floor is uneven then this can lead to vibrations and disturbing noises.



Fig. 5: Unit installation

! NOTICE!

There must be a minimum clearance of 20 cm between the rear of the unit and the wall.

- All extensions to the power supply must be of a sufficient cable size and must only be used fully rolled out.



Fig. 6: Power supply

REMKO MKT

- Check whether the stopper in the condensate drain is present and correctly installed. There is a risk of uncontrolled condensate leakage after commissioning.



Fig. 7: Condensate drain

- 1: Condensate drainage with stopper

- Never operate the unit without the air inlet filter. Otherwise, the fins of the heat exchanger can become dirty and the unit loses performance.



Fig. 8: Air inlet filter

- 1: Recirculated air filter

- Ensure that persons and sensitive objects, such as plants, are not placed directly in the air flow emerging from the unit.



In addition, with direct solar radiation close the curtains and blinds and keep the windows and doors closed during operation.

Conduct the warm exhaust air away

! NOTICE!

The exhaust air hose should always be laid rising in the direction of air flow and must not be extended!

In cooling mode the unit creates warm moist exhaust air, which must be conducted away from the room to be cooled. For this reason it is necessary to plug the exhaust air hose into the outlet opening on the rear of the unit.

- Ensure that the catches for the exhaust air hose latch securely into the two openings of the connection aperture. In order to be sure of effective operation, do not lay the flexible exhaust air hose with tight bends and do not kink it and to prevent damage resulting to avoid air carrying components!



Fig. 9: Latch the hose into place

- The exhaust air of the unit contains a certain amount of moisture. For this reason it is advisable to feed the exhaust air to the outdoor area or to outdoors.

Exhaust air routing variants

You can route the exhaust air out of the building as follows:

Via a flat nozzle

The flat nozzle supplied can be used in various different ways. It is possible to feed the flat nozzle through an open window and fasten it by means of Velcro and a window suction cup (Fig. 10). Likewise the flat nozzle can be hung in a tilted window (Fig. 11).

Via a wall pass-through

The hose supplied is firmly attached to a wall pass-through. A suitable wall pass-through is available as an accessory (Fig. 12).




Fig. 10: Exhaust air with open window




Fig. 11: Exhaust air with tilted window



Fig. 12: Wall pass-through

! NOTICE!

In some circumstances routing the exhaust air via a firmly attached exhaust air hose, e.g. through closed doors or windows, can lead to negative pressure in the room in which the unit is being used. If this should reduce the performance of the unit then arrange for the pressure to be equalised (provide ventilation if necessary on-site).

REMKO MKT

Installation scheme for wall pass-through (accessory)




Fig. 13: Installation example

- | | |
|--------------------|--------------------|
| 1: External grill | 3: Non-return flap |
| 2: Telescopic tube | 4: Sealing cover |

Installation instructions

1. Create a core hole in the exterior wall (max. wall thickness 480 mm) with a diameter of at least 135 mm. Watch out for any supply lines in this area!
2. Insert the slide tube into the wall pass-through created such that the outer tube (larger diameter) is on the inside of the wall. In order to avoid cold bridges insulate the telescopic tube with suitable insulation material.
3. Brick the slide tube into the core hole such that it sits flush on both sides of the wall.
4. Fasten the protection grid on the outside of the wall with 4 screws. Take rain ingress into account when fitting the grid.
5. Insert the interior flap valve and fasten this likewise with 4 screws. The "Top" legend on the flap valve must be visible from the inside.
6. When decommissioning the unit, e.g. before the start of the winter period, seal the opening in the flap valve with the sealing cover in order to prevent air circulation.

6 Electrical wiring

Electrical drawings




Fig. 14: Electrical drawings

A:	Mains power circuit board	5:	Condenser fan
B:	Control panel control board	6:	Condensate motor
C:	Power plug	Colour coding:	
1:	Microswitch (reservoir)	Br	Brown
2:	Temperature sensor, recirculated air	Bu	Blue
3:	Evaporator fan	Rd	Red
4:	Compressor	Wh	White

We reserve the right to modify the dimensions and design as part of the ongoing technical development process

REMKO MKT

7 Commissioning

Before every commissioning the air inlet and outlet openings should be checked for foreign bodies and the air inlet filter must be checked for dirt. Blocked or soiled grids and filters must be cleaned immediately, see "Care and maintenance" chapter.

Cooling mode

1. ▶ Switch the unit on with the "POWER" key.
2. ▶ Select cooling mode with the "MODE" key. The "COOL" LED must illuminate.
3. ▶ Set the desired target temperature with the "TIMER/TEMP/ADJUST" key. The selected target temperature will be shown in the display. If the fan stage selected is too large or too small then this can be adjusted with the "FAN SPEED" key.

Recirculation mode

1. ▶ Switch the unit on with the "POWER" key.
2. ▶ Select ventilation mode with the "FAN SPEED" key. The "HIGH/MED/LOW" LED must illuminate.

8 Troubleshooting and customer service

The unit has been manufactured using state-of-the-art production methods and has been tested several times to ensure that it works properly. If malfunctions should occur, please check the unit as detailed in the list below. Please inform your dealer if the unit is still not working correctly after all the function checks have been performed.

Operational malfunctions

Fault description	Cause	Remedy
The unit does not operate, the control panel remains dark	Mains voltage	Ensure that mains voltage is present (fuse)
	Power failure	Check voltage and if necessary wait until turned on again.
	Mains fuse or controller fuse faulty	Arrange to have exchanged
	Power plug not inserted in socket	Insert power plug
	Power supply defective	Check power supply for damage
The unit is working with reduced performance	Exhaust air or outlet openings are dirty or blocked by foreign bodies	Clean the openings, remove foreign bodies
	Filter soiled	Clean the filter in accordance with the instructions
	Cooling load of the room excessive	Reduce the thermal load
The unit does not work, LED indicator "Timer" is flashing	"Timer"	Timer is programmed, delete the timer setting.
The unit does not work, display shows "E1"/"H1"	Room temperature	This lies outside the operational limits of 16 to 35°C. Wait until the room temperature lies within the operating range (reduce the solar radiation and close windows and doors if necessary).
The unit switches itself off automatically, malfunction LED flashes and a signal sounds (reservoir full)	Reservoir full	Proceed as follows to empty the reservoir: 1. Switch unit off, pull out power plug. 2. Place a shallow container underneath the drain outlet and loosen the stopper. 3. After the condensate has drained off, plug the stopper back in again firmly.

REMKO MKT

Fault description	Cause	Remedy
The unit does not cool properly	LED cooling indicator	The "Cool" LED indicator must illuminate
	Close windows, doors, blinds and curtains	
	Exhaust air hose	Must be properly attached. It must not be kinked, sloping downwards or laid in bends that are too tight.
	Air feed and air exhaust	There must be no foreign bodies impairing these (observe minimum clearance)
	Ventilation louvres	Must be free of dirt and foreign objects
	Target temperature adjustment	Must not be set too high (unit operating range +16 to +35 °C).
The unit does not respond to the remote control	Remote control	There must be no objects between the remote control and the unit (range ca. 5 m).
	Batteries	Ensure that the batteries are in good working order, otherwise replace the batteries the batteries have been inserted with the correct polarity (see markings)
Condensate leaks out of unit	Unit standing at an angle	Position vertically, ensure stable horizontal base
	Stopper in condensate drain hose missing	Seal the hose so that it is watertight again
	Exhaust air hose not correctly seated	Connect correctly

9 Care and maintenance

Regular care and observation of some basic points will ensure trouble-free operation and a long service life.

DANGER!

Prior to performing any work, ensure the equipment is disconnected from the voltage supply and secured to prevent accidental switch-on!



Fig. 15: Filter removal

1 Filter

- Clean the unit using a damp cloth. Do not use a jet of water.
- Do not use any caustic, abrasive or solvent-based cleaning products.
- Only use suitable cleaning agents, even in the event of severe soiling.
- Ensure that no moisture gets into the unit. Clean the exhaust air and outlet openings regularly and thoroughly. This is where dirt most often collects first

NOTICE!

Check the level of dirt on the on the exchanger fins.

- Clean the air filter on the indoor unit at regular intervals, and more frequently if necessary.
- It is recommended that you take out a maintenance contract with an appropriate specialist firm.



This enables you to ensure the operational reliability of the plant at all times!

Filter cleaning

The unit is equipped with an air filter. This can be withdrawn from the rear of the unit. The filter must be cleaned at regular intervals. Clean the air filter at intervals of no more than 100 operating hours. Reduce this interval in the case of heavily contaminated air.

Please proceed as follows in order to clean the unit:

1. ➤ Switch the unit off and pull out the power plug.
2. ➤ Pull the filter out of the unit (Fig. 15)
3. ➤ Clean the dust off the filter. Use a vacuum cleaner in the event of slight soiling. (Fig. 16)
4. ➤ In the case of heavy soiling clean the filter carefully in lukewarm water. (Fig. 17)
5. ➤ Subsequently allow the filter to dry in the air.
6. ➤ Insert the filter back into the device.
7. ➤ Ensure that the filter is dry and undamaged.

NOTICE!

Never operate the indoor unit without the original filter. The heat exchanger fins on the indoor unit with soil up if operated without a filter and the device will suffer performance loss.



Fig. 16: Cleaning with a vacuum cleaner

REMKO MKT




Fig. 17: Cleaning with lukewarm water

10 Shutdown

! NOTICE!

Never switch off the equipment by pulling out the mains plug.

Temporary shutdown

If it is planned to shut down the unit for longer periods e.g. during the winter, proceed as follows:

1. ➤ Let the unit run in recirculating operation for ca. 2 hours in order to dry the surfaces of the evaporator fins. This will transport the remaining moisture out of the unit and this will avoid unpleasant odours when the unit is re-commissioned.
2. ➤ Switch the unit off with the "POWER" key, pull out the power plug and wind up the power supply. Ensure that the wiring is not kinked or too severely bent.
3. ➤ Place a suitable container underneath the condensate drain of the internal reservoir. The condensate drain is located on the lower rear side of the unit.
4. ➤ Pull out the stopper from the condensate drain and collect the condensate that drains out.
5. ➤ Then insert the stopper once again. A missing stopper or an incorrectly inserted stopper will result in condensate leaking out after re-commissioning.
6. ➤ Store the unit in an upright position in a cool, dry and dust-free location protected from direct sunlight. Cover the unit with a synthetic cover to protect it against dust if desired.

Permanent shutdown

The entire system should only be dismantled by a specialist firm familiar with all environmental aspects involved. REMKO GmbH & Co. KG or your sales partner will be pleased to provide details of refrigerant specialists in your area.

11 Exploded view and spare parts lists

11.1 Exploded view of the unit



Fig. 18: Exploded view

We reserve the right to modify the dimensions and design as part of the ongoing technical development process.

REMKO MKT

11.2 Spare parts list

For ordering spare parts, please contact directly to the REMKO GmbH & Co. KG.
All their device the accompanying part numbers can be found in the download area on www.remko.de.



IMPORTANT!

To ensure the correct delivery of spare parts, please always the device type with the corresponding serial number (see type plate)

No.	Description	MKT 251	MKT 251 <i>S-LINE</i>
1	Unit base		
2	Conveyor rollers		
3	Condensate pump with impeller 12VDC		
4	2.5 µF capacitor (condenser fan)		
5	Float (reservoir)		
6	Cover (reservoir)		
7	Microswitch (reservoir)		
8	Compressor, cpl.		
9	25 µF capacitor (compressor)		
10	Condenser		
11	Fan housing (condenser fan)		
12	Fan impeller (condenser fan)		
13	Fan motor (condenser fan)		
14	Condensate tray		
15	Exhaust air nozzle		
16	1.5 µF capacitor (evaporator fan)		
17	Evaporator		
18	Fan housing (evaporator fan)		
19	Fan impeller (evaporator fan)		
20	Fan motor (evaporator fan)		
21	Mains power circuit board		
22	Power supply with plug		
23	Front panel		
24	Back wall		
25	Air outlet fins, set		
26	Control panel control board		
27	Control panel		
28	Air filter		
29	Exhaust air hose		

By request with the serial number

No.	Description	MKT 251	MKT 251 <i>S-LINE</i>
30	Connection nozzle	By request with the serial number	
31	Window nozzle		
32	Condensate drain nozzle with stopper		
33	Remote control		
	Exhaust air hose cpl. (no. 29; 30; 31)		
Spare parts not illustrated			
	Ambient air probe	By request with the serial number	
Accessories			
	Wall pass-through	1613115	1613115

REMKO MKT

12 Index

A		
Assembly	11	
C		
Care and maintenance	19	
Cleaning the filter	19	
Condensate drain	12	
Conduct the warm exhaust air away	12	
D		
Disposal of equipment	6	
E		
Environmental protection	6	
Exhaust air routing variants		
Via a flat nozzle	12	
Via a wall pass-through	13, 14	
Exploded view drawing	21	
Exploded view of the unit	21	
I		
Installation	11	
M		
Maintenance	19	
O		
Operation		
Control panel	9	
		Dehumidifying mode 10
		Operating mode "Mode" 10
		Ventilate mode 10
	R	
	Recirculated air filter	12
	S	
	Safety	
	Dangers of failure to observe the safety	
	notes	4
	General	4
	Identification of notes	4
	Notes for inspection	5
	Notes for installation	5
	Notes for maintenance	5
	Personnel qualifications	4
	Safety notes for the operator	5
	Safety-conscious working	4
	Unauthorised modification	5
	Unauthorised replacement part manufacture	5
	Set-up	11
	W	
	Warranty	5

REMKO MKT

REMKO INTERNATIONAL

*... and also right in your neighbourhood!
Make use of our experience and advice*



REMKO GmbH & Co. KG
Air conditioning and heating technology

Im Seelenkamp 12 D-32791 Lage
Postfach 1827 D-32777 Lage
Telephone +49 5232 606-0
Telefax +49 5232 606-260
E-mail info@remko.de
Website www.remko.de

Consulting

Thanks to intensive training, our consultants are always completely up-to-date in terms of technical knowledge. This has given us the reputation of being more than just an excellent, reliable supplier:

REMKO, a partner helping you find solutions to your problems.

Distribution

REMKO offers not just a well established sales network both nationally and internationally, but also has exceptionally highly-qualified sales specialists.

REMKO field staff are more than just sales representatives: above all, they must act as advisers to our customers in air conditioning and heating technology.

SFIbCustomer Service

Our equipment operates precisely and reliably. However, in the event of a fault, REMKO customer service is quickly at the scene. Our comprehensive network of experienced dealers always guarantees quick and reliable service.

